

Special Reminders

Procedure Overview Instructions & Explanations

🚫 Long clothing, gloves, full face respirator, safety boots

⚠️ 1 Ensure the platform and ladder are placed so that you can access the valve safely

⚠️ 2 Ensure liquid is drained from all low spots in hose

⚠️ 3 Check for leaks. If a leak occurs turn valve off immediately

📄 1 Special note on reverse side

📄 1 Picture on front side

📄 2 Picture on front side

📄 3 Picture on front side

📄 4 Picture on front side

📄 1 Enlarged picture on reverse side

📄 2 Enlarged picture on reverse side

📄 3 Enlarged picture on reverse side

📄 4 Enlarged picture on reverse side

🔧 Obtain all tools & materials listed on reverse side

📄 PPM – BIGN_HO

1 Prepare Equipment

✓ **Pre-Checks** (See reverse side)

- 1.1 Position yourself upwind of the applicator tank.
- 1.2 Turn the liquid withdrawal valve on the applicator tank off. ⚠️ 1 📄 1
- 1.3 Clear system of liquid and pressure. 📄 1 📄 1
- 1.4 Put on your PPE. 🔧

2 Remove Strainer 🚫

- 2.1 Disconnect the high pressure hose from the metermatic. 📄 2 🔧
- 2.2 Drain liquid from hose. 📄 3 ⚠️ 2
- 2.3 Remove the strainer from the metermatic. 📄 2

3 Clean and Replace strainer 🚫

- 3.1 Clean strainer.
- 3.2 Clean rubbish from the metermatic inlet. 📄 3
- 3.3 Replace the strainer. 📄 4
- 3.4 Reconnect the high pressure hose. 🔧 🔧

4 Return equipment for normal operation 🚫

- 4.1 Turn the metermatic off.
- 4.2 Slowly open the liquid withdrawal valve. ⚠️ 3 📄 4
- 4.3 Remove PPE

✓ **Post-Checks** (See reverse side)

📄 1 ⚠️ 1.2 Turn the liquid withdrawal valve on the applicator tank off.



📄 2 2.1 Disconnect the high pressure hose from the metermatic



📄 3 ⚠️ 2.2 Drain liquid from hose



📄 4 3.3 Replace the strainer.



Strainer

✓ **Pre-Checks** (Things to check before starting this process)

- Check and prepare PPE ready for use
- Check wind direction

🔧 Tools & Materials Required

ID	Qty	Description	Step
PPE	1	<input type="checkbox"/> Personal Safety Kit	1.4
	1	<input type="checkbox"/> 18" shifter	2.1 & 3.4

✓ **Post-Checks** (Things to check after completion)

- Check and clean PPE
- Return PPE to Personal Safety Kit

i #1 **1.3** Clear System of Liquid and pressure

1. Turn metermatic on.
2. Leave metermatic open.

Indicates On



#2 **2.3** Remove the strainer from the metermatic



Strainer

#3 **3.2** Clean rubbish from the metermatic inlet.



Inlet

#4 **⚠️** **3.4.2** Slowly open the liquid withdrawal valve.

